

Envisioning a Greener Tomorrow



Greening the Cleaning®
It is our mission to provide the public with the safest and most environmentally responsible cleaning products possible.

DESCRIPTION:

This product is a safer formulation than the vast majority of finishes available. It is free of Zinc, Butyle Ether and Formaldehyde while being lower in Ammonia and Silicone. This pleasant smelling finish is highly detergent resistant, extremely reflective and is more durable than most metal-interlocked finishes. This product is much better for the environment, among the highest gloss finishes and is one of the most durable in the world.

DIRECTIONS:

STRIP AND RECOAT

Before application, remove old coatings with Clear Cut Concentrate Stripper. Pick up stripper solution using wet vacuum. Thoroughly rinse and neutralize floor. No sealer required except for new floors, very porous floors, or very high traffic. If so, apply 1-2 coats of Sealer/Finish. Apply 3-4 coats of Zinc-Free Floor Finish. Allow at least 15 min after dry to touch between coats.

SCRUB AND RECOAT

Recoat ever 4-8 weeks, or as needed. Dry mop area. Scrub with blue or green pad and General Purpose Cleaner. Rinse & let dry. Apply 1-2 coats of Zinc-Free Floor Finish.

Zinc-Free Floor Finish

DIC12 640.13

CLEANING - RESTORING GLOSS

Dry mop daily. Burnish regularly - recommend (Aqua pad.) Do not use Hog's Hair pad.

CLEAN AND SHINE /Automatic Scrubber

Dry mop. Clean with neutral floor cleaner - use a red pad. Allow floor to dry - burnish (Aqua pad).

Mop & Bucket

Dry mop. Clean with neutral floor cleaner and damp mop. No rinse required. Let dry - burnish (Aqua pad).

SIZES:

4 - 1 gallon case

5 gallon drum

ANIMAL RIGHTS

- Contains no animal-derived ingredients.
- Finished product has not been tested on animals.

ENVIRONMENTAL AND HEALTH

All ingredients are biodegradable. Free of petroleum distillates, ammonia and ammonium compounds, alkyl cello-solves, chlorinated solvents, pine oil and phosphates. Gray Water and Septic Tank Safe.

PACKAGING

Please rinse empty container with water and refill with this product or take it to your recycling center. This product is packaged in plastic that is recyclable and which may contain up to 25% recycled plastic materials. Shipping boxes may contain up to 50% post consumer waste.

Non-for-Profits Helping Non-for-Profits

100% of all profits from our institutional products go to the Center for supporting education and research to identify, control and ultimately prevent exposures to environmental factors that may cause adult, and especially pediatric cancer, as well as other health problems with our children.

The Deirdre Imus Environmental Center
for Pediatric Oncology®
at
Hackensack University Medical Center

Proudly Packaged & Distributed By
Central Association for the Blind and Visually Impaired

We support the employment and rehabilitation services of people who are blind and visually impaired.



Central Association
for the Blind
and Visually Impaired

507 Kent Street Utica, New York 13501
Fax # 315-792-3678 or Toll Free Number # 877-611-5611